

RUBYFIRES®

Crackling Sound Effect Box Manual



Product Features

Bluetooth Version: 4.0

Built-in Hi-Fi speaker

Supports MP3 Files Stored In TF card

Audio Input for Devices without Bluetooth Function

Built-in Rechargeable Battery

Resume/Memory Function

High Quality Audio Codec Chip for perfect audio performance
Radio function

Specifications



Output power:3W

Degree of Distortion <10%

Effective Operating Range:8-10m D

Imensions:D61xH60mm

Net Weight:155g



Basic Functions

1, Long press POWER ON/OFF Model key Bluetooth/Aux/radio/TF card

2, Long press Volume + Short press: The next song, The next channel, in the radio state

3, Play/Pause, Double click will search for channels in the radio state

4, Long press Volume + Short press: The last song / The last channel, in the radio state

5, TF card socket

6, LED

7, DC 5 V/USB charging and audio input port

8, Reset when press button 4 and button 2 at the same time

Operating instructions

1 - Open power key enter to the bluetooth connection mode, please connect with mobile phone bluetooth device,Bluetooth pairing name:BT-SPEAKER I

2 - Open the speaker again: automatically search the last connection to the bluetooth device, if searching the last device more than 10 seconds, will exit the connection status,If it is found that the last connection to the bluetooth device, automatically connect

3 - press the (Mode) key to enter the bluetooth/audio input/radio/TF card mode conversion

4-In radio mode, to insert of charging line (antenna) first, click button 2 to search channels, will store the channels after searching... press button 2 or 4 this key to choose the last / the next channels selection

5- After bluetooth connection, Can transfer the music of the mobile , through the button control the music like the last/next song, volume +/- volume - ,pause/play , such as action, specific see key definitions.