








Bubble Wall & Floor










1. FLOOR OPTION





2. WALL OPTION





Installation manual Senso Burner (I1495)